Naval Research Laboratory

Washington, DC 20375-5000

AD-A212 707



NRL Memorandum Report 6531

Cold Tests of Quasi-Optical Gyrotron Resonators

R.P. FISCHER, T.A. HARGREAVES* AND A.W. FLIFLET

Beam Physics Branch Plasma Physics Division

*Mission Research Corp. Newington, VA 22122

September 7, 1989



Approved for public release; distribution unlimited.

09 9 20

134

CECLIBITY	CLASSIEIC	ATION OF	THIS PAGE	

SECURITY CLASSIFICATION OF THIS PAGE					,
REPORT DOCUMENTATION PAGE			Form Approved OM8 No. 0704-0188		
1a REPORT SECURITY CLASSIFICATION UNCLASSIFIED	V 21. 2121 711 12712 2 1 1 1 1 1 1 1 1 1 1 1		MARKINGS	•	
2a. SECURITY CLASSIFICATION AUTHORITY		3. DISTRIBUTION			
2b. DECLASSIFICATION / DOWNGRADING SCHEDU	LE	unlimited.	or public :	reiease	e; distribution
4. PERFORMING ORGANIZATION REPORT NUMBER	R(S)	5. MONITORING	ORGANIZATION	REPORT N	UMBER(S)
NRL Memorandum Report 6531					
6a. NAME OF PERFORMING ORGANIZATION	7a. NAME OF MONITORING ORGANIZATION				
Naval Research Laboratory	Code 4794				
6c. ADDRESS (City, State, and ZIP Code)		7b. ADDRESS (City, State, and ZIP Code)			
Washington, DC 20375-5000					
8a. NAME OF FUNDING / SPONSORING ORGANIZATION	8b. OFFICE SYMBOL (If applicable)	9. PROCUREMEN	T INSTRUMENT I	DENTIFICA	TION NUMBER
DOE	<u> </u>	<u> </u>			
Bc. ADDRESS (City, State, and ZIP Code)		10. SOURCE OF	PROJECT	TASK	WORK UNIT
Washington, DC 20545		ELEMENT NO.	NO.	NO.	ACCESSION NO. DN780-307
11. TITLE (Include Security Classification)		<u></u>			
Cold Tests of Quasi-Optical G	yrotron Resonat	ors			
12. PERSONAL AUTHOR(S)	A 3 777	A 77			
Fischer, R.P., Hargreaves,* T. 13a TYPE OF REPORT 13b TIME C		, A.W. 14. DATE OF REPO	ORT (Year Mont)	h Day) 1	5. PAGE COUNT
Interim FROM	to	1989 Sept		,,,,	31
16. SUPPLEMENTARY NOTATION					
*Mission Research Corp., Newi	ngton, VA 22122				
17. COSATI CODES	18. SUBJECT TERMS (Continue on rever	se if necessary a	nd identify	by block number)
FIELD GROUP SUB-GROUP	Quasicoptica Cold tests	1 gyrotron	✓Open Scale		raction theory,
<u> </u>	Quality fact	or	DCGTC	ı dill	raction theory,
19. ABSTRACT (Continue on reverse if necessary	and identify by block r	number)			<u> </u>
Cold tests are performed on a number of quasi-optical gyrotron resonators at 94 and 120 GHz to determine the variation of cavity Q with mirror separation. The separation between the resonator mirrors is varied between 15 and 35 cm, with measured quality factors ranging from 10,000 to 100,000. Good agreement is obtained between the measured data and values calculated from scalar diffraction theory. The effect of misaligning the mirrors is also examined experimentally.					
20. DISTRIBUTION/AVA LABILITY OF ABSTRACT 121 UNCLASSIFIED/UNLIMITED SAME AS	RPT DTIC USERS	21. ABSTRACT SI UNCLASS		ICATION	
222 NAME OF RESPONSIBLE INDIVIDUAL Richard P. Fischer	226, TELEPHONE (202) 76	(Include Area Cod 73765	de) 22c. C	OFFICE SYMBOL ode 4794	
			67.61.017		CATION OF THIS BACE


DD Form 1473, JUN 86

Previous editions are obsolete.

CONTENTS

I.	INTRODUCTION	1
n.	QUASI-OPTICAL RESONATORS	3
m.	COLD TEST APPARATUS	4
IV.	RESULTS	5
	ACKNOWLEDGEMENTS	7
	REFERENCES	7
	DISTRIBUTION LIST	19





COLD TESTS OF QUASI-OPTICAL GYROTRON RESONATORS

I. Introduction

Gyrotrons are currently under development as efficient, high-power sources of millimeter waves. The trend is toward higher power (> 1 MW average) and higher frequency (submillimeter wavelengths). Waveguide cavity gyrotrons are presently the leading candidate for electron cyclotron heating of fusion plasmas. However, these conventional cavity gyrotrons suffer from large ohmic heating, transverse mode competition, and electron beam collection problems as power and frequency are increased. The quasi-optical gyrotron (QOG) was proposed by Sprangle, Vomvoridis, and Manheimer in 1980^{2,3,4,5} and has the potential to overcome each of these difficulties.

The quasi-optical resonator is comprised of a pair of spherical mirrors separated by many wavelengths. The QOG operates in a series of TEM_{00l} modes, where l > 100 for cw relevent configurations. Higher order transverse modes can be made to suffer from large diffraction losses due to the finite size of the mirrors. The diffraction of the TEM_{00l} modes around one or both of the mirrors is collected as output.

Typical round-trip diffraction losses are several percent. This output coupling sensitively depends upon the mirror size, radius of curvature, and separation. For a given pair of mirrors, output coupling is increased by increasing the separation between the mirrors. However, the radiation waist near the center of the cavity is relatively insensitive to changes in separation. Thus, the output coupling can be varied independently with respect to the interaction length. This is a unique feature of the QOG, and is quite advantageous experimentally.

The electron beam direction is perpendicular to the axis of the resonator, which allows the beam to be collected separately from the radiation. This is an important feature for high-power devices and eases restrictions on the collector. It also facilitates the use of depressed collector technology. The cavity mirrors are well removed (> 10 cm) from the wave/beam interaction region, which reduces the ohmic heating density at the mirrors.

The quality factor (Q) of a resonator is an important parameter which describes how well the cavity stores energy and is closely related to the output coupling. The Q for a

Fabry-Perot-type resonator can be very large. Quality factors on the order of 100,000 are typical for resonators used in recent experiments at the Naval Research Laboratory. Since the balance between ohmic effects and diffraction is very important in the QOG, a detailed experimental study is called for.

Fabry-Perot resonators have been used for years to measure the microwave properties of solids, liquids, and gases.⁶ These cavitites have proven to be quite useful. For permittivity and loss measurements, the design goal is to make the Q as large as possible. This is accomplished by making the mirrors large so that diffraction losses are negligible. Energy is typically coupled into the cavity through coupling holes or a dielectric beam splitter.

Cold tests of gyrotron cavities are difficult to perform in practice. Most cold-test schemes involve drilling coupling holes into the cavity walls, which can perturb the cavity mode severely. It is also difficult to couple efficiently to the mode of interest, which is frequently a high-order mode. Woskoboinikow et al. radiated their conventional gyrotron cavities in the far field and analyzed the reflected signal. This technique has the advantage of being nondestructive, so that the hot test cavity may be used for the cold test. It is difficult to test a QO cavity this way because little energy is coupled into the resonator mode.

Although the QOG is an advanced concept, it operates in the fundamental Gaussian mode. This makes coupling to the correct mode very easy. This study uses the method of Perrenoud et al.⁹ where a small hole is used to couple energy into the resonator and diffracted power is collected with a standard gain horn as output. This technique has a distinct advantage in that there is no background radiation pattern on the oscilloscope trace, which increases the accuracy of the measurement. The majority of the measurements in this article concern the variation of Q with separation for various cavities. Good agreement is obtained between measured values and calculations based on scalar diffraction theory. The effect of misaligning the mirrors is also examined experimentally.

II. Quasi-Optical Resonators

The Q of a Fabry-Perot-type resonator can be written

$$Q = \frac{4\pi L}{\lambda f_L} \tag{1}$$

where L is the separation between mirrors, λ is the free-space wavelength, and f_L is the fractional round-trip loss. In practice, this loss factor includes ohmic losses, diffraction losses, and losses due to coupling holes. These are the three loss mechanisms which are important in this study. The total Q of the resonator can be expressed as

$$\frac{1}{Q} = \frac{1}{Q_{\Omega}} + \frac{1}{Q_{d,c}} \tag{2}$$

where Q_{Ω} is the ohmic Q, and $Q_{d,c}$ is the Q due to diffraction and coupling losses. The ohmic Q is calculated using the formula

$$Q_{\Omega} = \frac{L}{4} (f \pi \mu_0 \sigma)^{\frac{1}{2}}. \tag{3}$$

In this expression, μ_0 is the permeability of free space and σ is the conductivity of the mirrors. Silver- and gold-plated mirrors are used in the cold tests, with conductivities 6.15×10^7 and 4.5×10^7 Siemens/m, respectively. The ohmic Q increases linearly with separation and is unimportant for large output coupling.

The diffraction/coupling Q is calculated separately from the ohmic Q. This is accomplished by a computer code which is based on a scalar Huygen's formulation. Inputs to the code include the wavelength of the radiation, the mirror radius, the radius of curvature of the mirrors, the separation between the mirrors, and the dimensions of a coupling hole. Some of these parameters are illustrated in Figure 1. The program also models cavities where the mirrors are not identical. Outputs from the code include $Q_{d,c}$, the balance between Q_d and Q_c , and the electric field distribution along the surface of each mirror for the TEM₀₀ and TEM₀₁ modes. Other modes may also be analyzed.

A chief obstacle to performing cold tests of millimeter-wave resonators is coupling power into the cavity without perturbing the Q too seriously. In this study, a small coupling hole

is drilled through the center of one mirror. The size of the hole is chosen to minimize degradation of Q while coupling a meaningful amount of power into the cavity. The radius of the coupling hole is 0.38 mm. The calculated effect of the coupling hole can be seen in Figure 2. For separations greater than 20 cm, there is practically no difference between the two resonators. In the present Naval Research Laboratory QOG experiment, the separation can be varied between 20 and 28 cm. This resonator lies well within the confocal instability point at 38.7 cm separation and the concentric stability limit at 77.4 cm separation. Thus, this cold test cavity should be a good model for the experiment. Below 20 cm, any change in the round-trip losses results in a large change in the total Q, due to the small output coupling. Figure 3 shows the round-trip transmission loss due to diffraction as a function of separation for the cavity analyzed in Figure 2. The transmission varies between 2.5% to 6% in the range of interest.

III. Cold Test Apparatus

The experimental set-up is similar to that adopted by Perenoud et al.⁹ A schematic diagram is shown in Figure 4. The entire arrangement is located on an optical table, with the quasi-optical mirrors mounted on six-inch diameter optical mounts which can be translated by hand on a rail.

A 0.76-mm diameter coupling hole pierces the left mirror. It is counterbored from behind, leaving a .005- to .010-inch wall. A WR-8 waveguide is inserted from the back of the coupling mirror for input, while a standard gain horn intercepts a small amount of the diffracted signal as output. In practice, the pick-up horn is placed next to the coupling mirror so that it may remain stationary while the far mirror is translated.

Two millimeter-wave sources are used for the measurements. The first is a 94 GHz IMPATT which produces 20 mW of power. Its frequency is swept by applying a 1-volt ramp to the FM port. The second source is a 120 GHz reflex klystron with a power output of several milliwatts. It is also swept with a low-voltage ramp, which is amplified in the klystron power supply/modulator and applied to the reflector. It is desirable to have a

linear frequency sweep versus time for the millimeter-wave source. This allows for direct measurement of the full width at half maximum (FWHM) from the oscillocope with no corrections. Typical sweeps are 20 MHz for this work and are linear over the range of interest for most resonators.

A detector/amplifier manufactured by Millitech Corp., which has a sensitivity of 50 V/mW, is used to observe the small signals collected by the radiation pick-up. The detector and its power supply are shielded, which reduces the noise on the oscilloscope to 0.1 mV. Typical resonances observed on the oscilloscope are 1-2 mV. The horizontal trace is calibrated using the interferometer in Figure 4. The interferometer is comprised of two six-inch diameter mirrors and has a Q of approximately 70,000. The separation can be varied between 32 and 43 cm, with fine adjustments facilitated by a micrometer graduated to 0.0001 inches. The interferometer would not be required if the quasi-optical cavity was mounted with a precision micrometer.

The resonator mirrors are made of oxygen-free, high-conductivity (OFHC) copper. They are machined, polished, and then plated with either silver or gold. The surface finish is $\lambda/20$ for $\lambda=10\mu\mathrm{m}$. Thus, surface scattering of millimeter waves should be negligible. The mirrors have a 0.5-mm bevel at the mirror's edge, which decreases the effective diameter by 1.0 mm.

A unique feature of the cold test arrangement is that the resonator mirrors are aligned with an HeNe laser. The incident beam defines the axis of the resonator, so that the mirror angle can be optimized by aligning the reflected and incident beams. The coupling hole is used to full advantage by passing the beam through the hole for centering and alignment. The resonator mirrors can be quickly aligned to better than $\frac{1}{10}$ °.

IV. Results

Figure 5 shows measured and calculated values of Q versus separation for a resonator with 4.6-cm diameter mirrors. The coupling hole is 0.76 mm in diameter and the frequency is 120 GHz. The radius of curvature is 38.7 cm for each of the mirrors used in this work.

The agreement between data and theory is quite good for separations greater than 20 cm, which is the region of operation the QOG. Measured values are somewhat higher than predicted at closer separations. This discrepancy may be due to the coupling hole.

A second set of measurements is shown in Figure 6. The frequency is 94 GHz, the resonator mirrors are 5.6 cm in diameter, and the coupling hole is 0.76 mm in diameter. The agreement between measured and calculated values is quite good. This resonator is similar to the resonator in Figure 5 in terms of Q.

Figure 7 shows data obtained with the 4.6-cm mirrors measured at 94 GHz. The values for Q are much lower due to increased diffraction losses at the longer wavelength. A Q of 7,000 corresponds to a round-trip transmission coefficient of 18% for a separation of 26 cm.

The present QOG utilizes a symmetric cavity; the mirrors are identical. Future configurations may include asymmetric resonators which couple power from one side only. Figures 8 and 9 show measured and calculated Q's for slightly asymmetric cavitites. There is diffraction around both mirrors, with more loss from the smaller mirror. The code accurately predicts the properties of these asymmetric cavities.

Another valuable measurement is the effect of misaligned mirrors on the Q. Perrenoud et al.⁹ found that 0.5° tilt resulted in a 50% degradation of Q for their configuration. This information is important because the mirrors must be attached to the magnet dewar, and it is difficult to estimate how well the dewar flanges are aligned. Figure 10 shows the effect of mirror misalignment on Q for one of the asymmetric cavities. The mirror separation is 15.8 cm and the frequency is 94 GHz. The Q begins degrading after 1° of misalignment. By 2°, the Q is reduced by 20%. The small scatter of the data for tilts less than 1° is indicative of the reproducibility of the measurement. In general, the sensitivity of the resonator to misalignment depends upon mirror size and separation. Increasing the separation to 25 cm has little effect on sensitivity to alignment for this cavity.

There are several sources of error in these measurements of Q versus separation. If the frequency sweep is not perfectly linear in time, a systematic error will be present. Secondly, there is a random error in reading the FWHM from the oscilloscope. A third source of error

is due to the slightly asymmetric shape of the resonance on the oscilloscope. Adjusting the pick-up horn usually corrects this problem. Hence, the measured values should be accurate to better than $\pm 10\%$. This error can be lowered to below $\pm 5\%$ with calibration and careful technique.

Acknowledgements

This work was supported by the Office of Fusion Energy of the Department of Energy and the Office of Naval Research.

References

- ¹ "CW Operation of a 140 GHz Gyrotron," K. Felch, B. Bier, L.J. Cragi, H. Huey, L. Ives, H. Jory, N. Lopez, and S. Spang, Int. J. Elec. 61, 701 (1986).
- ² "Theory of the Quasi-Optical Electron Cyclotron Maser," P. Sprangle, J. Vomvoridis and W. Manheimer, Phys. Rev. A 23, 3127 (1981).
- ³ "Multimode Time Dependent Analysis of Quasi-Optical Gyrotrons and Gyroklystrons," A. Bondeson, W.M. Manheimer and E. Ott, Phys. Fluids 26, 285 (1983).
- Multimode Analysis of Quasi-Optical Gyrotrons and Gyroklystrons," A. Bondeson,
 B. Levush, W. Manheimer and E. Ott, Int. J. of Electronics 53, 547 (1982)
- ⁵ "Cavity Design for Quasi-Optical Gyrotron or Gyroklystron Operation at Harmonics of the Cyclotron Frequency," B. Levush and W. Manheimer, Intl. J. Infrared and Millimeter Waves 4, No. 6, 877 (1983)
- ⁶ "Fabry-Perot and Open Resonators at Microwave and Millimeter Wave Frequencies, 2-300 GHz," R.N. Clark and C.B. Rosenberg, J. Phys. E 15, 9-24 (1982).

- ⁷ "Loaded Q's and Field Profiles of Tapered Axisymmeteric Gyrotron Cavities," H. Derler, T.J. Grant, and D.S. Stone, IEEE Trans. Electron Devices, Vol ED-29, pp 1917-1929 (1982).
- * "Nondestructive Gyrotron Cold Cavity Measurements," P. P. Woskoboinikow and W. J. Mulligan, IEEE Trans. Microwave Th. and Tech., Vol MTT 35, No. 2, pp 96-100 (1987).
- "Low Power Measurements of the Quality Factor of an Open Resonator with Stepped Mirrors," A. Perrenoud, M.Q. Tran, B. Isaak, A. Alberti, and P. Muggli, Intl Jour. of Infrared and Millimeter Waves 7, No. 11, pp 1813-1822 (1986).
- Code written by K. Yoshioka, with a formulation similar to that found in "Open Resonator for Quasi-Optical Gyrotrons: Structure of the Modes and Their Influence," A. Perrenoud, T.M. Tran, M.Q. Tran, C. Rieder, M. Schlepipen, and A. Bondeson, Int. Journal of Electronics 57, No. 6, pp 985-1001 (1984).







Figure 1 Cross section of a quasi-optical resonator showing two different sized mirrors with a hole for input coupling.




The calculated effect of a coupling hole on the cavity Q. The solid curve diameter coupling hole (frequency =120 GHz, mirror diameter = 4.6 cm, radius of is the resonator without the hole; the dashed curve is for a cavity with a 0.76-mm curvature = 38.7 cm). Figure 2




= 120 GHz, mirror diameter = 4.6 cm, radius of curvature = 38.7 cm). The separation is Round-trip transmission coefficient versus mirror separation (frequency typically varied between 20 and 28 cm in the QOG.




Schematic diagram of the cold-test apparatus. Output is collected as diffraction around one of the quasi-optical mirrors. Figure 4




Measured (open dots) and theoretical values (solid curve) of cavity Q versus mirror separation (frequency = 120 GHz, mirror diameter = 4.6 cm, radius of curvature = 38.7 cm, hole diameter = 0.76 mm). Figure 5




versus separation (frequency = 94 GHz, mirror diameter = 5 6 cm, radius of curvature = Measured (open dots) and theoretical value: (solid curve) of cavity Q 38.7 cm, hole diameter = 0.76 mm). Figure 6




versus separation (frequency = 94 GHz, mirror diameter = 4.6 cm, radius of curvature = Measured (open dots) and theoretical values (solid curve) of cavity Q 38.7 cm, hole diameter = 0.76 mm). Figure 7



Measured (open dots) and theoretical values (solid curve) of cavity Q diameter = 4.6(5.0) cm, radius of curvature = 38.7 cm, hole diameter = 0.76 mm). versus separation for an asymmetric resonator (frequency = 120 GHz, mirror 1(2) Figure 8



Measured (open dots) and theoretical values (solid curve) of cavity Q diameter = 4.6(5.6) cm, radius of curvature = 38.7 cm, hole diameter = 0.76 mm). versus separation for an asymmetric resonator (frequency = 120 GHz, mirror 1(2) Figure 9



Cavity Q versus mirror misalignment (frequency = 94 GHz, mirror 1(2) diameter = 5.0(5.6) cm, radius of curvature = 38.7 cm, hole diameter = 0.76 rnm). Figure 10

4793/4 DISTRIBUTION LIST

Air Force Avionics Laboratory		
AFWAL/AADM-1		
Wright/Patterson AFB, OH 45433 Attn: Walter Friez		
Attn: waiter filez	Ţ	copy
Air Force Office of Scientific Research		
Bolling AFB		
Washington, D.C. 20332	_	
Attn: H. Schlossberg	1	copy
Air Force Weapons Lab		
Kirkland AFB		
Albuquerque, NM 87117		
Attn: Dr. William Baker		copie
Dr. A.H. Guenter	1	copy
Bhabha Atomic Research Center		
Laser Division		
Bombay, India 400085		
Attn: T.S. Shirsat	1	сору
Columbia University		
Columbia University 520 West 120th Street		
Department of Electrical Engineering		
New York, NY 10027		
Attn: Dr. S.P. Schlesinger	1	сору
A. Sen	1	copy
Columbia University		
520 West 120th Street		
Department of Applied Physics		
and Nuclear Engineering		
New York, NY 10027		
Attn: T.C. Marshall		copy
R. Gross	1	copy
Cornell University		
School of Applied and Engineering Physics		
Ithica, NY 14853		
Attn: Prof. Hans H. Fleischmann		cobà
John Nation R. N. Sudan		сору
R. N. Sudan	_	сору
Creol-FEL Research Pavillion		
12424 Research Parkway, Suite 400		
Orlando, FL 32826		
Attn: Dr. Luis R. Elias		copy
Dr. I. Kimel	1	copy

Dartmouth College 18 Wilder, Box 6127 Hanover, NH 03755 Attn: Dr. John E. Walsh 1 copy Defense Advanced Research Project Agency/DEO 1400 Wilson Blvd. Arlington, VA 22209 Attn: Dr. L. Buchanan 1 copy Defense Communications Agency Washington, D.C. 20305 Attn: Dr. Pravin C. Jain Assistant for Communications Technology 1 copy Defense Nuclear Agency Washington, D.C. 20305 Attn: Mr. J. Farber 1 copy Dr. Leon Wittwer (RAAE) 5 copies Defense Technical Information Center Cameron Station 5010 Duke Street Alexandria, VA 22314 2 copies Department of Energy Div. of Advanced Energy Projects Washington, DC 20545 Attn: Dr. R. Gajewski 1 copy Department of Energy Office of Energy Research Washington, D.C. 20545 Attn: C. Finfgeld/ER-542, GTN 1 copy T.V. George/ER-531, GTN 1 copy 1 copy D. Crandall/ER-54, GTN Dr. David F. Sutter/ER-224, GTN 1 copy Director of Research U. S. Naval Academy Annapolis, MD 21402-5021 1 copy General Atomics 13-260 Box 85608 San Diego, CA 92138 ATTN: Dr. J. Doane 1 copy Dr. C. Moeller 1 copy

Georgia Tech. EES-EOD Baker Building Atlanta, GA 30332 Attn: Dr. James J. Gallagher	1	сору
Hanscomb Air Force Base Stop 21, MA 01731 Attn: Lt. Rich Nielson/ESD/INK	1	сору
Hughes Aircraft Co. Electron Dynamics Division 3100 West Lomita Boulevard Torrance, CA 90509 Attn: J. Christiansen J. Tancredi		copy
Hughes Research Laboratory 3011 Malibu Canyon Road Malibu, CA 90265 Attn: Dr. R. Harvey Dr. R.W. Schumacher		copy
KMS Fusion, Inc. 3941 Research Park Dr. P.O. Box 1567 Ann Arbor, MI 48106 Attn: S.B. Segall	1	сору
Lawrence Berkeley Laboratory University of California 1 Cyclotron road Berkeley, CA 94720 Attn: Dr. A.M. Sessler	1	сору
Lawrence Livermore National Laboratory P.O. Box 808		
Livermore, CA 94550 Attn: Dr. D. Prosnitz Dr. T.J. Orzechowski Dr. J. Chase Dr. W.A. Barletta Dr. D.L. Birx Dr. R. Briggs Dr. E.T. Scharlemann	1 1 1 1	copy copy copy copy
Litton Electron Devices 960 Industrial Road San Carlos, CA 94070 Attn: Library	1	сору

```
Los Alamos National Scientific Laboratroy
P.O. Box 1663, MSJ 564
Los Alamos, NM 87545
       Dr. Brian Newman
                                                    1 copy
Los Alamos Scientific Laboratory
P.O. Box 1663, AT5-827
Los Alamos, NM 87545
       Dr. T.J.T. Kwan
Attn:
                                                    1 copy
        Dr. L. Thode
                                                    1 copy
        Dr. C. Brau
                                                    1 copy
        Dr. R. R. Bartsch
                                                    1 copy
Massachusetts Institute of Technology
Department of Physics
Cambridge, MA 02139
       Dr. G. Bekefi/36-213
Attn:
                                                    1 copy
        Dr. M. Porkolab/NW 36-213
                                                   1 copy
        Dr. R. Davidson/NW 16-206
                                                   1 copy
        Dr. A. Bers/NW 38-260
                                                    1 copy
        Dr. K. Kreischer
                                                    1 copy
        Dr. B. Danby
                                                    1 copy
        Dr. G.L. Johnston
                                                    1 copy
Massachusetts Institute of Technology
167 Albany St., N.W. 16-200
Cambridge, MA 02139
       Dr. R. Temkin/NW 14-4107
Attn:
                                                    1 copy
Mission Research Corporation
8560 Cinderbed Road, Suite 700
Newington, VA 22122
Attn: Dr. M. Bollen
                                                    1 copy
        Dr. Tom Hargreaves
                                                    1 copy
        Dr. J. Pasour
                                                    1 copy
Naval Research Laboratory
Addressee: Attn: Name/Code
Code 0124 - ONR
                                                    1 copy
Code 1000 - Commanding Officer
                                                    1 copy
Code 1001 - T. Coffey
                                                    1 copy
Code 1003.9A - Computer Resources Architect
                                                    1 copy
Code 1005 - Head, Office of Mgt. & Admin.
                                                    1 copy
Code 1005.1 - Deputy Head, Off. of Mgt. & Admin.
                                                    1 copy
Code 1005.6 - Head, Directives Staff
                                                    1 copy
Code 1200 - Capt. M.A. Howard
                                                    1 copy
Code 1201 - Deputy Head, Command Support Division 1 copy
Code 1220 - Security
                                                    1 copy
Code 2000 - J. Brown
                                                    1 copy
Code 2604 - NRL Historian
                                                    1 copy
Code 2628 - TID Distribution
                                                   22 copies
Code 2634 - Cindy Sims
                                                    1 copy
Code 3000 - R. Doak
                                                    1 copy
```

Code 4000 - W. Ellis Code 4000 - D. Nagel Ccde 4700 - S. Ossakow Code 4700.1 - A. Ali Code 4790 - Branch Office Code 4790 - W. Black Code 4790 - G. Cooperstein Code 4790 - A. Fliflet Code 4790 - S. Gold Code 4790 - C. Hui Code 4790 - C. Kapetanakos Code 4790 - A. Kinkead Code 4790 - Y. Lau Code 4790 - W. Manheimer Code 4790 - W. Manheimer Code 4790 - M. Rhinewine Code 4790 - P. Sprangle Code 5700 - L. Cosby Code 6840 - S. Ahn Code 6840 - R. Parker Code 6840 - N. Vanderplaats Code 6850 - L. Whicker Code 6875 - R. Wagner	1 copy 1 copy 26 copies 1 copy 25 copies 1 copy
Naval Sea Systems Command Department of the Navy Washington, D.C. 20362 Attn: Commander, PMS 405-300	l copy
Northrop Corporation Defense Systems Division 600 Hicks Rd. Rolling Meadows, IL 60008 Attn: Dr. Gunter Dohler	1 copy
Oak Ridge National Laboratory P.O. Box Y Mail Stop 3 Building 9201-2 Oak Ridge, TN 37830 Attn: Dr. A. England	1 сору
Office of Naval Research 800 N. Quincy Street Arlington, VA 22217 Attn: Dr. C. Roberson	1 copy
Office of Naval Research 1012 W 36th Street, Childs Way Bldg. Los Angeles, CA 90089-1022 Attn: Dr. R. Behringer	1 Copy

Optical Sciences Center University of Arizona Tucson, AZ 85721 Attn: Dr. Willis E. Lamb, Jr.	1 copy
Physical Science Inc. 603 King Street Alexandria, VA 22314 ATTN: M. Read	1 copy
Physics International 2700 Merced Street San Leandro, CA 94577 Attn: Dr. J. Benford	1 copy
Princeton Plasma Plasma Physics Laboratory James Forrestal Campus P.O. Box 451	
Princeton, NJ 08544 Attn: Dr. H. Hsuan Dr. D. Ignat Dr. H. Furth Dr. P. Efthimion Dr. F. Perkins	2 copies 1 copy 1 copy 1 copy 1 copy
Raytheon Company Microwave Power Tube Division Foundry Avenue Waltham, MA 02154 Attn: N. Dionne	1 copy
Sandia National Laboratories ORG. 1231, P.O. Box 5800 Albuquerque, NM 87185 Attn: Dr. Thomas P. Wright Mr. J.E. Powell Dr. J. Hoffman Dr. W.P. Ballard Dr. C. Clark	1 copy 1 copy 1 copy 1 copy 1 copy
Science Applications, Inc. 1710 Goodridge Dr. McLean, VA 22102 Attn: Adam Drobot P. Vitello D. Bacon C. Menyuk	1 copy 1 copy 1 copy 1 copy
Science Research Laboratory 15 Ward Street Somerville, MA 02143 Attn: Dr. R. Shefer	1 copy

SPAWAR Washington, D.C. 20363 Attn: E. Warden, Code PDE 106-3113 Capt. Fontana, PMW 145	1 copy 1 copy
Spectra Technologies 2755 Northup Way Bellevue, WA 98004 Attn: Dr. J.M. Slater	1 copy
Stanford University Dept. of Electrical Engineering Stanford, CA 94305 Attn: Dr. J. Feinstein	1 copy
Stanford University High Energy Physics Laboratory Stanford, CA 94305 Attn: Dr. T.I. Smith	l copy
Stanford University SLAC Stanford, CA 94305 Attn: Dr. Jean Labacqz	1 copy
TRW, Inc. One Space Park Redondo Beach, CA 90278 Attn: Dr. H. Boehmer Dr. T. Romisser Dr. Z. Guiragossian	1 copy 1 copy 1 copy
University of California Physics Department Irvine, CA 92717 Attn: Dr. G. Benford Dr. N. Rostoker	1 copy 1 copy
University of California Department of Physics Los Angeles, CA 90024 Attn: Dr. A.T. Lin Dr. N. Luhmann	1 copy 1 copy 1 copy
Dr. D. McDermott University of Maryland Department of Electrical Engineering College Park, MD 20742 Attn: Dr. V. L. Granatstein Dr. W. W. Destler	1 copy 1 copy 1 copy

University of Maryland Laboratory for Plasma and Fusion Energy Studies College Park, MD 20742 Attn: Dr. Tom Antonsen Dr. John Finn Dr. Jhan Varyan Hellman Dr. W. Lawson Dr. Baruch Levush Dr. Edward Ott Dr. M. Reiser	1 copy 1 copy 1 copy 1 copy 1 copy 1 copy 1 copy
University of New Mexico Department of Physics and Astronomy 800 Yale Blvd, N.E. Albuquerque, NM 87131 Attn: Dr. Gerald T. Moore	1 copy
University of Tennessee Dept. of Electrical Engr. Knoxville, TN 37916 Attn: Dr. I. Alexeff	1 copy
University of Utah Department of Electrical Engineering 3053 Merrill Engineering Bldg. Salt Lake City, UT 84112 Attn: Dr. Larry Barnett Dr. J. Mark Baird	1 copy 1 copy
U. S. Army Harry Diamond Labs 2800 Powder Mill Road Adelphi, MD 20783-1145 Attn: Dr. Howard Brandt Dr. Edward Brown Dr. Stuart Graybill Dr. A. Kehs	1 copy 1 copy 1 copy 1 copy
Dr. J. Silverstein Varian Associates 611 Hansen Way Palo Alto, CA 94303	1 copy
Attn: Dr. H. Huey Dr. H. Jory Dr. Kevin Felch Dr. R. Pendleton Dr. A. Salop	1 copy 1 copy 1 copy 1 copy 1 copy
Varian Eimac San Carlos Division 301 Industrial Way San Carlos, CA 94070 Attn: C. Marshall Loring	1 copy

WL/CA Kirtland AFB, NM 87117-6008 Attn: Mr. Brendan B. Godfrey

1 copy

Yale University
Applied Physics
Madison Lab
P.O. Box 2159
Yale Station
New Haven, CN 06520
Attn: Dr. I. Bernstein

1 copy

Ken Busby

1 copy